



the paint the professionals use

NEW INTERIOR TIMBER DOORS

Condition: New

Note: *All surfaces of the doors especially the bottom edge must be painted with the full paint system. We recommend this is done while off their hinges.*

PREPARATION FOR PAINTING:

- 1.1 Thoroughly sand to a smooth, clean surface. Sand any sharp arrisses to a rounded profile. Wipe surface with a damp rag to remove dust.
- 1.2 Prime with Resene Quick Dry Acrylic Primer Undercoat at the spreading rate of 12-13 square metres per litre. **Data Sheet D45**

Note: *If any staining is visible after the primer coat then a stain blocking coat of Resene Enamel Undercoat will be needed.*

Note: *On Customwood / particle board type surfaces water borne coatings may raise the grain slightly. If this occurs lightly wet sand to produce a smooth finish. Wipe clean.*

- 1.3 Fill all holes and cracks with Selleys No More Cracks Interior or equivalent product applied in accordance with manufacturers directions. When dry sand smooth and spot prime with Resene Quick Dry Acrylic Primer Undercoat.

PAINTING:

For a Semi gloss finish

- 1.4a Apply a full coat of Resene Lustacryl at the spreading rate of 12 square metres per litre. Allow 2 hours dry. **Data Sheet D310**
- 1.5a Apply a finishing coat of Resene Lustacryl at the spreading rate of 12 square metres per litre.

For a Gloss finish

- 1.4b Apply a full coat of Resene Enamacryl at the spreading rate of 12 square metres per litre. Allow 2 hours dry. **Data Sheet D309**
- 1.5b Apply a finishing coat of Resene Enamacryl at the spreading rate of 12 square metres per litre.